

Panel Type: A1

Top Rail



Fig. 401/54
Top Glass
Door Rail

Top Fixings: *None*

Bottom Rail: *None*

Bottom Fixings




Fig. 403/75
Bottom Glass
Door Rail

Panel Type: A2

Top Rail



Fig. 401/54
Top Glass
Door Rail

Top Fixings: *None*

Bottom Rail




Fig. 403/75
Bottom Glass
Door Rail

Bottom Fixings: *None*

Panel Type: A3

Top Rail: 398-75

Top Fixings: *None*

Bottom Rail




Fig. 403/75
Bottom Glass
Door Rail

Bottom Fixings: *None*

Panel Type: A4

Top Rail: 398-75

Top Fixings: *None*

Bottom Rail




Fig. 403/75
Bottom Glass
Door Rail

Bottom Fixings: *None*

Panel Type: A5

Top Rail




Fig. 403/75
Bottom Glass
Door Rail

Top Fixings: *None*

Bottom Rail: 398-75

Bottom Fixings: *None*